

When DMR-HWT250GL use it, there will be the following differences. Please understand.

## <Order Remote>



N2QAYB001042

## <Shared Remote>



N2QAYB001039

### Increasing buttons

[INPUT SELECT] : Invalid button

\*Shown with  in figure.

### Missing buttons

[DISPLAY] : Playback Settings

Replace it with [OPTION] >Playback Menu >Playback Settings

\*Shown with  in figure.

### Other differences

[MODEL NAME] :HDD RECORDER ⇒ BLU-RAY DISC RECORDER

\*Shown with  in figure.